

TELEPHONE ENTRY SYSTEM

INFINITY



REFINED, ROBUST, RELIABLE.

Engineered for exceptional performance and functionality, the InFINITY Series combines the convenience of telephone entry with the flexibility of access control.

This dynamic combination is designed with an extensive feature set to meet today's needs and tomorrow's growth. Each control panel can support card and code access for 2 doors or gates. In addition, the InFINITY has the ability to network up to 16 panels for larger installation requirements.

Perfect for securing any size office building or gated residential community. The LCDs utilize a high-contrast ratio and bright backlight for clear viewing in a wide range of environmental conditions. Names and codes are entered into the system through a handheld programmer or remotely with the optional SPSWin software.

LCD Display Features:

The InFINITY M supports 2 lines of 20 characters each, 1/2"H.

The InFINITY L boasts a large display, offering your choice of either 24 names of up to 13 characters each, or commercial firmware offering 12 names of up to 35 characters each.

The InFINITY B, with no display, can be installed alone or in conjunction with other InFINITY models.

LiftMaster®

INFINITY

SOFTWARE FEATURES

Access Levels

Infinity systems allow entry codes or cardholders to be grouped in any number of ways for precision access control of employees and visitors.

Remote Management

The software is carefully designed to offer virtually unlimited site management from a single host computer through the telephone line or direct connect. When it's necessary to download information from the database, SPS Win streamlines the process of the distribution to the individual systems.

Tenant Manager

A user-friendly window that simplifies the day-to-day management of tenant records such as adding names, directory codes, entry codes and card codes. This feature also supports multiple units sharing a single database. In this configuration updates can be sent to a single unit or a group of units.

Data Exchange

Used to manage the automatic upload and download of data between the PC and the unit. This function is capable of performing on schedule, allowing for unattended data transfers based on time of day and frequency.

Historical Reporting

The ERMAWin utility aids in evaluating historical transactions with the use of customer-defined reports, charts and graphs. If required, it also has exporting capabilities to transfer information to a spreadsheet.

OPTIONAL WARRANTIES

Model	Extended Warranties		Lightning
	Variable per year list price	Fixed 5 year list price	First year only list price
Infinity (S,M&D)	\$130.00 /year	\$400.00	\$330.00
Infinity L	\$270.00 /year	\$770.00	\$550.00
Infinity B	\$90.00 /year	\$270.00	\$220.00

INFINITY ACCESSORIES

BWCAMKT

Black & White Camera Kit (available for Infinity M & L models)

CCAMKT

Color Camera Kit (available for Infinity M & L models)

SNMHTR

Heater, Factory Installed (available for the Infinity L, assists in cold weather climates)

SNASASHM

Stand-Alone Short-Haul Modem (for use between the computer and the first Infinity in a Multi-Link Chain)

SNMMODB

Internal 2400 Baud Modem

SNAPPL

Mounting Plate, Large (required for post mounting)

SNAPEDG

Gooseneck Pedestal Post (gray)

SNARKLS

Small Remote Keypad in a Lighted Housing

SNAARM

Auxiliary Relay Module (for elevator control)

IMFMKT

Flush Mount Kit for Infinity M Models

ILFMKT

Flush Mount Kit for Infinity L Models

SNATSURGE

Telephone Line Surge Suppressor (for added protection to the phone line inputs during low-voltage storm surges)

SNALSURGE

Low-Voltage Surge Suppressor (for added protection to the power inputs during low-voltage storm surges)

No Phone Bill Option

SNANPBI

No-Phone-Bill Interface (converts standard Infinity M or L into a system that will not generate a phone bill)

Note: Requires line interface boards, housings, cables & RJ71 jacks.

SNALIB3

Line interface board (Interfaces up to 12 lines each)

SNALIBHS LIB

Housing Small (holds up to 3 LIB's)

SNALIBHL LIB

Housing Large (holds up to 10 LIB's with Power Supplies for LIB's and Connector Board)

SNALIBCBL 25 Pair Cable (15' Length)

Use to connect LIB's and RJ71 jacks.

SNARJ71 RJ71 Jack

Use in connecting up to 12 resident lines to an LIB

SPECIFICATIONS

Infinity M

Directory Codes

500, 1000

Full Entry Codes with Names

2000, 3000

Full Entry Codes without Names

16,000

Event Buffer

5800

Surface Mount Dimensions

16"H x 11.75"W x 4.25"D

Flush Mount Back Box Dimensions

16.375"H x 12.8"W x 3.125"D

Power

12VAC @ 3.4 amps peak, 13.5VDC @1.2 amps (without readers)

Shipping Weight

21 lbs.

Infinity L

Directory Codes

500, 1000

Full Entry Codes with Names

1000 (L only), 2000 (L only), 3000

Event Buffer

5800

Surface Mount Dimensions

21"H x 16.4"W x 4.375"D (hood protrudes 7" out from faceplate)

Flush Mount Back Box Dimensions

21.3"H x 16.75"W x 3.125"D

Power

12VAC @ 3.4 amps peak, 13.5VDC @ 2.1 amps (without readers)

Shipping Weight

Infinity L: 35 lbs.,
Infinity L with hood: 36 lbs.,
Infinity DI: 32 lbs.

Infinity B

Full Entry Codes with Names

4000

Full Entry Codes without Names

20,000

Event Buffer

5800

Outdoor Housing - Surface Mount Dimensions

16"H x 11.75"W x 3.25"D

Power

12VAC @ 3.4 amps peak, 13.5VDC @ 1.0 amp (without readers)

Shipping Weight

30 lbs.

1 YEAR WARRANTY

(Extended Warranties Available)

LiftMaster®

THE CHAMBERLAIN GROUP, INC.
845 Larch Avenue • Elmhurst, IL 60126

www.liftmaster.com

